



NOTE :

1. BACKFILL POLE EXCAVATION WITH LIMESTONE SCREENINGS WELL TAMPERED TO WITHIN 150mm OF THE CENTRE OF THE SUBGRADE HANDHOLE.
2. POSITION FLEX CONDUIT INTO SUBGRADE HANDHOLE
3. BACKFILL REMAINING POLE EXCAVATION WITH SOIL, FREE FROM STONE AND ANY OTHER DEBRIS AND LEVELLED TO MATCH EXISTING GRADE.
4. REINSTATE AREA TO MATCH EXISTING CONDITIONS.
5. INSTALLATION DEPTH IS 10% OF POLE HEIGHT PLUS 610mm
6. 50mm FLEXIBLE PVC CONDUIT TO PROTECT CABLE AT POLE APERTURE SEE FIGURE A

ALL DIMENSIONS IN mm UNLESS OTHERWISE NOTED